

# SURE STEP™



- **WORLD'S FIRST PRESSURE SENSITIVE NON-SKID DECK POLISH**
- **COVERAGE: 200sq. ft. ONE COAT (8oz jar), 3,200sq. ft. ONE COAT (1US Gal Jug)**

SURE STEP™ contains a unique new polymer "SKID-X™" that seals, shines and protects non skid boat surfaces against dirt penetration and accumulation without making the surface slippery, tacky or sticky. Grip increases when the surface is wet.

## **DIRECTIONS:**

### **Shake Well Before Using.**

1. Wash surface with BOAT CLEAN PLUS™ to remove any traces of wax, oil or pollutants and to loosen grime in the gelcoat pores.
2. Scrub surface with BOAT SCRUB™ and a stiff bristle brush (deck brush) on non-skid areas and a Marine Power Mitt on smooth areas to remove oxidation, stains, scuffs and deep clean the gelcoat pores. Rinse well and let dry.
3. Apply SURE STEP™ with white, high density foam paint roller and let dry to a haze.
4. Buff to a beautiful shine with a SURE STEP BUFFING WHEEL™ on a portable drill. Wait 24 hours before applying second coat.

## **DO NOT FREEZE.**