

POLY GUARD™

PVC UV Protector



Regular use of POLY GUARD™ UV protector extends the life and appearance of your Inflatable Water Sports Equipment by protecting against deterioration from UV, pollution, scuff marks, grime, suntan lotion, soot, bird droppings, insect marks and most stains. Made from Space Age Polymers, it does not contain silicone, oils or wax and will not attack the fabric or seam adhesives. It will not stain clothes or make the surface slippery or greasy.

DIRECTIONS:

Inflate your equipment. For best results do not apply in direct sunlight and preferably in the late afternoon or early morning. Clean the entire surface with MAXI CLEAN™ (and SPEED CLEAN™ if your inflatable equipment is deteriorated). The surface must be clean and dry. Apply POLY GUARD™ to one section at a time. Pour POLY GUARD™ into a bucket or shallow container. Fold a clean white cloth into a pad and dip the edge, into the POLY GUARD™. Wipe excess off against the edge of the container. Apply by wiping on, in long even strokes, overlapping the wet edge until the entire surface is coated. Allow to dry. Continue to the next section until the entire unit is covered. Apply a second coat, starting at the first section and continuing until the entire unit is protected. Do not use your inflatable equipment until the surface is completely dry.

DO NOT APPLY TO HOT SURFACE, IN DIRECT SUNLIGHT, OR TO A WET OR DAMP SURFACE.

SHAKE WELL BEFORE USING

CAUTION:

In case of eye contact rinse immediately with plenty of water. In case of skin contact, wash with soap & water. If ingested, rinse mouth with water & drink 2-3 glasses of water to dilute. Only induce vomiting if directed by a physician. Seek medical advice. In all cases of doubt or when symptoms persist, seek medical attention.