

SPEED CLEAN™

- USE ON HYPALON, VINYL, RUBBER, FIBERGLASS, STAINLESS STEEL & CHROME
- CONTAINS HYPEXINE



Removes oxidation, chalking, scuffmarks, rust, grime, oil, bird droppings, insect marks and most stains from inflatable boats.

DIRECTIONS:

TEXTURED SURFACES:

Wet with water. Apply SPEED CLEAN™ and scrub with sponge or brush until clean. Rinse clean. Allow to dry thoroughly. Protect with POLY GUARD™ .

SMOOTH SURFACES:

Apply SPEED CLEAN™ and rub with damp sponge or cloth until Surface feels smooth, is cleaned and original colour is restored. Rinse with water. Wipe dry. Protect fiberglass with PREMIUM BOAT SHINE™. Protect tube and rubber with POLY GUARD™.

METAL:

Apply SPEED CLEAN™ to soft cloth and polish until metal gleams. Protect with PREMIUM BOAT SHINE™.

NOTE:

SPEED CLEAN™ contains HYPEXINE™ to leach stain out. Surface should be tested for colour fastness before cleaning.

SHAKE WELL BEFORE USING
DO NOT FREEZE

WARNING:

May cause skin & eye irritation. Do not swallow. Avoid Contact with eye & skin.

FIRST AID TREATMENT:

IF SWALLOWED:

Rinse mouth. Do NOT induce vomiting. Call a POISON CONTROL CENTER or doctor/physician if you feel unwell. IF IN EYES: Rinse them well with water.

IF ON SKIN:

Rinse well with water.